

Attributmanager aufrufen

Use the property manager to edit property sets and property set templates.



Note: The property manager is available only to the team owner and team administrators.

To open the property manager

This is only possible if ...

You are signed in to the **BIMPLUS** web portal (see "[Signing in to the BIMPLUS web portal](#)")
You are the team owner or team administrator of the Bimplus team

1. *Only if you are the owner or administrator of several Bimplus teams:*
Make sure the required team is the current team (see "[Selecting the current Bimplus team](#)").
2. Select the navigation menu by clicking  **Show navigation menu** on the title bar of the **BIMPLUS** web portal.
3. Click  **Property manager**.

You can see the three-column table of the property manager.

[Back to top](#)