


Objekte oder Teilmodelle anzeigen

To show objects or partial models in full view by means of the multimodel manager


This is only possible if ...

Multimodel manager is open (see "[Opening the multimodel manager](#)")

1. Go to the **Multimodel manager** palette and select the required structure in the **Select structure** list box.
2. Expand the structure as far as the required objects or the superordinate node and click  **Show**.

You can see the objects in the selected color in full view (see "[Changing the color for objects](#)").



Tip: Go to the toolbar at the bottom and click  **Isolate working objects**. Select the **Isolate** option to make all other objects of the overall model transparent. Select the **Hide unisolated** option to completely hide all other objects.

[Back to top](#)